CORE SAMPLE PRESS

MAINTAIN HIGH INTEGRITY SAMPLES

Available in N, H, and P sizes, the Hardwick Core Sample Press is designed to guarantee sample integrity in a variety of ground conditions.

Simply mount the inner-tube, drop the safety-cover over the piston, and run the press. From competent to highly fractured samples, the core press maintains continuity by extruding material from the inner-tube in easy-to-manage 5′ or 10′ (1.5m or 3.0m) segments. No sliding. No crumbles. No lost time.

- Designed for safety
- Run 5′ or 10′ (1.5m or 3.0m) rods
- Quick adapters for various conditions
- Easy to transport and setup
- Utilizes rig hydraulics
- Available in N, H, and P sizes

SAFER
Locked-down cage protects hands from interacting with the hydraulic press..

CONVENIENT
Easy to move and setup. Folding legs lock into position and all adapters are stored in the press.



EFFICIENT
Reduce manual assembly of highly-fractured samples. Increase productivity in all conditions.

www.hardwickmachinery.com

7272 South Airport Road Unit D
West Jordan, Utah 84084
USA

Phone +1 801-255-5733

© Copyright 2020, Hardwick,. All rights reserved. Version 1.25